

FOR SALE BY  
801 6742

AMPLIFIER

| APPLICATOR PARTS LIST |                                  |      |          | TYPE                 |  |          | BRUSH CONTACT       |  |              | RIGHT AMP INCORPORATED HARRISBURG, PENNA. |           |          | BOTH LEGS ON BLADE |  |
|-----------------------|----------------------------------|------|----------|----------------------|--|----------|---------------------|--|--------------|---|-----------|----------|--------------------|--|
| NO.                   | DESCRIPTION                      | REQ. | PART NO. | NO.                  | DESCRIPTION                            | REQ.     | PART NO.            | CRIMPING DATA  |              |   | TERMINALS |          |                    |  |
| 1                     | WIRE CRIMPER                     | 1    | 686916-2 | 42                   |  |          |                     | TO APPLY TERMINAL  |              |   | 62149     |          |                    |  |
| 2                     | INS. CRIMPER                     | 1    | 686917-1 | 43                   |  |          |                     | WIRE SIZE  | CRIMP HEIGHT |   |           |          |                    |  |
| 3                     | ANVIL WIRE                       | 1    | 464820-1 | 44                   |  |          |                     | 21   | .058         |   |           |          |                    |  |
| 4                     | ANVIL INS.                       | 1    | 458586-1 | 45                   |  |          |                     | 20   | .059         |   |           |          |                    |  |
| 5                     | SHEAR BLADE                      | 1    | 464822-1 | 46                   |  |          |                     | 19   | .061         |   |           |          |                    |  |
| 6                     | REAR SHEAR PLATE                 | 1    | 455444-1 | 47                   |  |          |                     | 18   | .063         |   |           |          |                    |  |
| 7                     | SHEAR BLADE SPACER-FRONT         | 1    | 686918-2 | 48                   | TERMINAL STOP                          | 1        | 686936-1            | 17   | .066         |   |           |          |                    |  |
| 8                     | SHEAR BLADE SPACER-REAR          | 1    | 373072   | 49                   | <del>DRAG STOP (REV. A OR LATER)</del> | 1        | <del>452835-1</del> | CRIMP SIZE TYPE FEED   |              |   |           |          |                    |  |
| 9                     | REAR ANVIL SPACER PLT.           |      |          | 50                   | DRAG BUSHING-FRT.                      | 1        | 452836-1            | WIRE   | .090         | F   |           |          |                    |  |
| 10                    | FRONT ANVIL SPACER PLT.          |      |          | 51                   | DRAG STUD-FRT.                         | 1        | 452837-1            | INSUL.   | .170         | 0   | .500      |          |                    |  |
| 11                    | TOOL SPACER                      |      |          | 52                   | DRAG SPRING-FRT.                       | 1        | 370572              | SLEEVED  |              |   |           |          |                    |  |
| 12                    | SPACER                           | 1    | 854652-8 | 53                   |  |          |                     | INSULATION RANGE   | WIRE RANGE   |   |           |          |                    |  |
| 13                    | FRONT STRIP GUIDE                | 1    | 385106-1 | 54                   |  |          |                     | .095-115   | 21-17 MAG.   |   |           |          |                    |  |
| 14                    | REAR STRIP GUIDE - BOT.          | 1    | 372895   | 55                   | SPACER, DRAG SKATE                     | 1        | 811834-7            | EXPLODED VIEW  |              |   |           |          |                    |  |
| 14A                   | REAR STRIP GUIDE - TOP           | 1    | 377723-2 | 56                   |  |          |                     | A-6000 9-9, -10  |              |   |           |          |                    |  |
| 15                    | RAM                              | 1    | 471911   | 57                   |  |          |                     | REMARKS:   |              |   |           |          |                    |  |
| 16                    | TOOL HOLDER                      |      |          | 58                   |  |          |                     | MODIFY GUARD TO CLEAR DRAG.  |              |   |           |          |                    |  |
| 17                    | ADJ. CRIMP MOUNT (REVERSE WEDGE) | 1    | 465392-6 | 59                   |  |          |                     | BUILT UP ANVIL TO RETAIN BLADE   |              |   |           |          |                    |  |
| 18                    | ADJ. BLOCK                       |      |          | 60                   |  |          |                     | TOOLING MT. SEQUENCE FROM ITEM 26 OUTWARD 61, 28 & 25  |              |   |           |          |                    |  |
| 19                    | APPLICATOR MOUNT ASSY.           | 1    | 458585-1 | 61                   | WIRE LOCATOR                           | 1        | 686913-1            | THIS DRAWING IS A CONTROLLED DOCUMENT FOR AMP INC. IT IS SUBJECT TO CHANGE AND THE CONTROLLING ENGINEERING ORGANIZATION SHOULD BE CONTACTED FOR THE LATEST REVISION. |              |   |           |          |                    |  |
| 20                    | BASE PLATE                       |      |          | 62                   |  |          |                     | DENOTES WEARING PARTS RECOMMEND PURCHASE REPLACEMENT   |              |   |           |          |                    |  |
| 21                    | BASE BLOCK                       |      |          | 63                   |  |          |                     | THIS APPLICATOR IS TO BE USED ON AMP-O-LECTRIC 1-471273-2  |              |   |           |          |                    |  |
| 22                    | STRIP GUIDE PLATE                |      |          | 64                   | 1" AIR FEED ASSY.                      | 1        | 690021-1            | AIR FEED   |              |   |           |          |                    |  |
| 23                    | ANVIL HOLDER                     |      |          | 65                   | TENSION ADJ. PLATE                     | 1        | 374999              | ALIGN. GA. 679597-1  |              |   |           |          |                    |  |
| 24                    | AUX. ANVIL HOLDER                |      |          | MISCELLANEOUS        |  |          |                     | SERIAL NO.   |              | DATE SHIPPED                              |           | DESIGNED |                    |  |
| 25                    | STRIPPER                         | 1    | 686914-1 | 66                   | LUBRICATOR ASSY.                       | 1        | 465184-2            | CUSTOMER NAME AND ADDRESS  |              | C.D.                                      |           | 2-8-77   |                    |  |
| 26                    | STRIPPER MOUNT (REAR MT.)        | 1    | 686912-1 | 67                   | TERMINAL LUBRICANT                     | REF      | 852931-2            | APP'D.   |              | SHEET                                     |           | 1 OF 2   |                    |  |
| 27                    | RETAINER PLATE                   | 1    | 372251   | 68                   | AIR BLAST ASSY.                        | 1        | 455350-1            | APPLICATOR NUMBER  |              | REV.                                      |           | 566131-2 |                    |  |
| 28                    | STRIPPER SPACER MT. BKT. 25461   | 1    | 471505-9 | 69                   | ELBOW                                  | 1        | 22317-3             | REV. E1  |              | SHEET                                     |           | 1 OF 2   |                    |  |
| 29                    | STRIPPER BUSHING                 |      |          | 70                   | COPPER TUBE                            | 1        | 689446-2            | REV. E1  |              | SHEET                                     |           | 1 OF 2   |                    |  |
| 30                    | STOCK DRAG SKATE                 | 1    | 801936-1 | 71                   |  |          |                     | REV. E1  |              | SHEET                                     |           | 1 OF 2   |                    |  |
| 31                    | STOCK DRAG HANDLE                | 1    | 389112   | 72                   |  |          |                     | REV. E1  |              | SHEET                                     |           | 1 OF 2   |                    |  |
| 32                    | STOCK DRAG STUD                  | 1    | 354045-1 | REV. REVISION RECORD |  |          | DATE                | BY   | ECN          |   |           |          |                    |  |
| 33                    | STOCK DRAG SPRING                | 1    | 123847-1 | A                    | REV. PER ECN                           | 8-78     | DIS. BIN            | R2660  |              |   |           |          |                    |  |
| 34                    | STOCK DRAG ADJ. SCREW            | 2    | 372997   | B                    | EC-A-272490                            | 10-10-90 | IS. CE              |  |              |   |           |          |                    |  |
| 35                    | FEED FINGER HOLDER               |      |          | C                    | ECN A-395892                           | 9-92     | MO. TB              |  |              |   |           |          |                    |  |
| 36                    | FEED FINGER                      | 1    | 452817-1 | D                    | 0150-5185-94                           | 1-99     | JB                  |  |              |   |           |          |                    |  |
| 37                    | FEED FINGER TIP                  |      |          | D1                   | 0150-6810-96 OBS.                      | 8-96     | TH                  |  |              |   |           |          |                    |  |
| 38                    | FEED FINGER SPACER               |      |          | E                    | 0150-8544-98                           | 6-98     | TH                  |  |              |   |           |          |                    |  |
| 39                    | BASE CASTING                     | 1    | 570238   | E1                   | 015A-0061-98                           | 9-98     | TH                  |  |              |   |           |          |                    |  |
| 40                    | GUARD                            | 1    | 457667-3 |                      |  |          |                     |  |              |   |           |          |                    |  |
| 41                    |                                  |      |          |                      |  |          |                     |  |              |   |           |          |                    |  |

